

PARTS LIST

TYPE 32/36 DGV 5A – PART NO. 22680.005

Dia No.	Qty. Req'd	Description	Part Number	Dia No.	Qty. Req'd	Description	Part Number
1	1	Carburetor Cover Assy.	31716.132	42	1	-Lever	Not Serviced
2	4	Stud Bolt	64955.002	43	1	-Screw Securing Wire	64615.004
3	6	Carb. Cover Fixing Screw	64700.001	44	1	Spring For Choke Lever	47610.058
4	1	Choke Shaft & Lever Assy.	10020.222	45	1	Bushing For Choke Lever	12775.010
5	2	Choke Valve	64010.007	46	1	Choke Lever Fixing Screw	64700.012
6	1	Split Pin	32610.005	47	1	Square Lever Fixing Screw	64700.012
7	1	Choke Rod	61287.008	48	1	Bushing For Square Lever	12775.010
8	1	Dust Seal Plug	61070.002	49	1	Fast Idle Control Square Lever Assy.	45096.025
9	1	Dust Seal Plate	52135.010	50	1	Split Pin	32610.005
10	1	Strainer Inspection Plug	61002.018	51	1	Spring For Square Lever	47610.033
11	1	Strainer Assy.	37022.010	52	1	Primary Throttle Adjusting Screw	64625.017
12	4	Choke Plates Fixing Screw	64525.003	53	1	Spring For Throttle Adjusting Screw	47600.007
13	1	Carb Cover Gasket	41705.035	54	1	Secondary Throttle Adjusting Screw	64595.005
14	1	Carb Power Valve Assy.	57804.052	55	1	Fast Idling Control Rod	61280.086
15	1	Float Fixing Pin	52000.015	56	1	Idle Adjusting Screw	64750.025
16	3	Control Valve Retaining Screw	64700.007	57	1	Spring For Idle Adjusting Screw	47600.007
17	3	Washer For Control Valve Screw	55510.038	58	1	Primary Throttle Control Lever	45046.020
18	1	Needle Valve Gasket	83102.070	59	2	Washer For Loose Lever	55510.061
19	1	Needle Valve Assy.	79519*	60	1	Fast Idling Loose Lever	45067.024
20	1	Float Assy.	41030.019	61	1	Wavy Washer	55530.002
21	1	Full Power Needle Valve Assy.	64235.016	62	1	Bushing For Loose Lever	12775.006
22	1	Power Valve Gasket	41530.013	63	1	Throttle Valve Control Lever	45136.029
23	1	Pump Discharge Blanking Needle	64900.001	64	1	Spring For Loose Lever	47605.010
24	1	Primary Main Jet	73801.*	65	1	Throttle Shaft Fixing Nut	34715.014
24A	1	Secondary Main Jet	73801.*	66	1	Lock Washer	55520.002
25	4	Shaft Retaining Bushing	12750.085	67	1	Loose Lever Assy.	45069.011
26	4	Bush Retaining Spring	47600.027	68	1	Secondary Shaft Fixing Nut	34705.001
27	1	Secondary Throttle Valve	64005.034	69	1	Spring Washer	5525.001
28	1	Secondary Shaft	10015.492	70	1	Washer For Loose Lever	55510.046
29	1	Primary Shaft	10015.493	71	1	Secondary Throttle Control Lever	45032.124
30	1	Primary Throttle Valve	64005.090	72	1	Carburetor Body	Not Serviced
31	4	Throttle Plate Fixing Screw	64520.023	73	1	Sheath Support Assy. –Including	58702.024
32	1	Shaft Return Spring	47610.079	74	1	-Sheath Support	58700.028
33	1	Spacer	12765.047	75	1	-Sheath Securing Plate	52145.001
34	1	Accelerator Pump Cover Assy.	32486.076	76	1	-Sheath Plate Fixing Screw	64615.007
35	4	Pump Cover Fixing Screw	64700.006	77	1	Sheath Support Fixing Screw	64700.012
36	1	Accelerator Pump Diaphragm Assy.	47407.249	78	1	Primary Emulsion Tube	61440.*
37	1	Pump Loading Spring	47600.092	78A	1	Secondary Emulsion Tube	61440.*
38	1	Primary Idle Jet	74403.*	79	1	Primary Air Corrector Jet	77201.*
38A	1	Secondary Idle Jet	74403.*	79A	1	Secondary Air Corrector Jet	77201.*
39	2	Gasket For Idling Jet Holder	41565.002	80	2	Pump Jet Gasket	41540.014
40	2	Idling Jet Holder	52570.006	81	1	Accelerator Pump Jet	76226.*
41	1	Choke Control Lever Assy. –Including	45202.064	82	1	Pump Delivery Valve Assy.	64290.024
		Calibrated Parts Require 3 Digits To		83	1	Auxiliary Venturi	71111.
		Complete Part Number.					
		See Calibrated Parts Section For Sizes					